



ENG Insect killer
CZ Lapač hmyzu
SK Lapač hmyzu



PLUG UV 230V

ENG Insect killer

Use:

- The trap is placed in an electrical outlet.
- The switch at the top of the device puts the device into operation.
- The trapping effect will be significantly more powerful in darker environments and especially at night.
- To turn it off, just turn the switch to the OFF position. And unplug the device.
- Cleaning is performed with the device switched off, the back is equipped with a drawer for emptying killed insects.
- Strictly follow the safety instructions!

Technical parameters:

Power	0.5 W
Trap grid voltage	900V
LED	4x SMD2835
Material	ABS
Power supply	230V ~ 50 Hz

Environmental protection guidelines

DISPOSAL:

Electrical appliances should not be disposed of with municipal waste. According to Directive 2002/96 / EC on Waste Electrical and Electronic Equipment (WEEE / WEEE) and related national legislation, electrical waste must be separated and recycled. Recycling as an alternative to disposal: the owner of the electrical equipment is obliged to return the equipment to a collection point or to ensure its proper recycling. Electrical waste can be disposed of at a waste collection point operated in accordance with applicable national waste directives. This does not apply to accessories without electrical components.

Warning:

High Voltage! Do not touch the internal electrical grid of the device. Children should be supervised to ensure that they do not play with the appliance.
Do not insert any foreign objects, especially metal objects, into the device.
Before putting the device into operation, check that the device is in order. Place the appliance out of the reach of children.
The insect trap must not be used in garages, stables and similar places. Keep the device away from flammable materials.
Keep the device out of the reach of children under 8 years of age.
The appliance may only be used by children over the age of 8 and people with reduced mental, sensory and mental capabilities, or by people with a lack of experience and knowledge, if they are given safe supervision while using the appliance or instructed on how to handle the appliance safely, to avoid injury. Children must not play with the appliance. Children must not attempt to clean or maintain the appliance unless they are supervised by a responsible person.
Make sure that children do not play with the appliance.
Regularly knock the collected dead insects out of the device. We recommend cleaning the device once a month or more often if necessary. Only clean the appliance when it is switched off and unplugged.
Never operate the device in a humid environment or in the rain.
The device must be switched off when not in use.
Do not use abrasive cleaners.
Do not clean under running water - this can lead to a short circuit or electric shock!

Caution:

This appliance must not be used by persons (including children) with reduced mental, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use by a person responsible for their safety.
Dangerous voltage!

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!