



DVD RECORDER

OWNER'S MANUAL

MODEL : DR7400

Before connecting, operating or adjusting this product,
please read this instruction booklet carefully and completely.





CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

WARNING: Do not install this equipment in a confined space such as a bookcase or similar unit.

CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
LUOKAN 1 LASER LAITE
KLASS 1 LASER APPARAT
CLASSE 1 PRODUIT LASER

CAUTION:

This product employs a Laser System. To ensure proper use of this product, please read this owner's manual carefully and retain it for future reference. Should the unit require maintenance, contact an authorized service center. Performing controls, adjustments, or carrying out procedures other than those specified herein may result in hazardous radiation exposure. To prevent direct exposure to laser beam, do not try to open the enclosure. Visible laser radiation when open. DO NOT STARE INTO BEAM.

CAUTION:

CLASS 2M VISIBLE AND INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED DO NOT STARE INTO THE BEAM OR VIEW DIRECTLY WITH OPTICAL INSTRUMENTS.

CAUTION: The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.



This product is manufactured to comply with the radio interference requirements of EEC DIRECTIVE 89/336/EEC, 93/68/EEC and 73/23/EEC.

CAUTION concerning the Power Cord

Most appliances recommend they be placed upon a dedicated circuit;

That is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits. Check the specification page of this owner's manual to be certain.

Do not overload wall outlets. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized servicer.

Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance.

SERIAL NUMBER:

You can find the serial number on the back of the unit. This number is unique to this unit and not available to others. You should record requested information here and retain this guide as a permanent record of your purchase.

Model No. _____

Serial No. _____

Contents

Introduction	4-8	Playback	24-30
Symbol Used in this Manual	4	Playing a DVD, Video CD, or Audio CD	24-27
Notes on Discs	4	Playing an MP3 File	28
Recordable and Playable Discs	5	Viewing a JPEG File	29
Playable Discs	5	Using the thumbnail menu for JPEG file	30
Disc-related terms	6	Using Playlist with MP3 or JPEG files	30
Front Panel and Rear Panel	7	Recording	31-34
Remote Control	8	About DVD recording	31
Remote Control Operation	8	Basic Recording from a TV	32
Hookup and Settings	9-23	OTR (One Time Recording)	32
Connections to Your TV and Aerial	9	Timer Recording	33
Connecting to an Amplifier	9	Checking Timer Recording Details	34
Accessory Audio/Video (A/V) Connections	10	Recording from an External Input	34
Auto Set Up	11	Editing	35-42
About DVD Recorder Initial Setup menu	11	Title List and Chapter List Menu Overview ...	35
Using the Initial Setup menu	12	Deleting a Title	36
TV Setup	12-14	Naming a Title	36
Auto Scan	12	Changing Title Thumbnails	37
Program Edit	13	Divide One Titles Into Two	37
Manual Setting	13	Adding Chapter Markers	38
Auto Install	14	Deleting Chapter Markers	38
Recording Setup	14	Hide a Chapter	38
Record Mode Set	14	Using the Disc Edit menu	39-42
Overwrite	14	Naming a Title	39
Chapter Mark	14	Erasing a Title	40
General Setup	15	Protect a Title	40
TV Display	15	Changing Title Thumbnails	40
Angle Mark	15	Editing a Title by Chapter	41
OSD (On-Screen Display) Language	15	Adding Chapter Markers	41
Last Memory	15	Deleting Chapter Markers	42
Clock Setting	15	Hide a Chapter	42
Video Setup	16	Overwriting Recording	42
Quality	16	Reference	43-47
Audio Setup	16-17	Controlling Your TV with the Supplied	
Post DRC (Dynamic Range Control)	16	Remote Control	43
SPDIF Setup	16	Language Codes	44
Dolby Digital	17	Area Codes	44
3D Surround	17	Troubleshooting	45-46
Preference	18-19	Specifications	47
TV Type	18		
Audio/Subtitle/Disc Menu Language	18		
Parent Control	18-19		
Default	19		
Using the Disc Operation menu	20-22		
Disc Erase	20		
Finalize	21		
Disc Protect	21		
Make Edits Compatible	21		
Adapt	22		
Disc Information	22		
General Explanation of On-Screen Display ...	23		
Using the On-Screen Display	23		

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!