



E G F S I Sw D Nr Fi De Po R Hg Cz Pl



HR-8TEC

User's Guide
Bedienungsanleitung
Mode d'emploi
Guía del usuario
Guida dell'utilizzatore
Instruktionshäfte
Gebruiksaanwijzing
Bruksanvisning
Käyttäjän opas
Brugsvejledning
Guia do Usuário
Инструкция по эксплуатации
Felhasználói Útmutató
Návod k použití
Instrukcja Obsługi



CASIO®

CASIO COMPUTER CO., LTD.

6-2, Hon-machi 1-chome
Shibuya-ku, Tokyo 151-8543, Japan

SA0602-A

Printed in China
Imprimé en Chine

CASIO®





GUIDELINES LAID DOWN BY FCC RULES FOR USE OF THE UNIT IN THE U.S.A. (not applicable to other areas).

NOTICE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modification to the product not expressly approved by CASIO could void the user's authority to operate the product.



CASIO Europe GmbH
Bornbarch 10, 22848 Norderstedt,
Germany



**Batterij niet weggooien,
maar inleveren als
KCA**





English

INDEX

NOTICE	1
■ Handling the Calculator	1
■ Battery Operation	1
■ AC Operation	2
■ About the Input Buffer	2
■ RESET Button	2
■ Errors	2
■ Auto Power Off	3
SETTINGS	44
■ To Load Batteries	44
■ AC Operation	47
■ Replacing the Ink Roller (IR-40)	48
■ Loading the Paper Roll	51
GENERAL GUIDE	54
■ Switching between Printing and Non-Printing ..	60
■ Printing Results Only	61
■ Date and Reference Number Printing	62
■ Decimal Mode	64
■ Calculations	68
■ Specifications	82



- Be sure to keep all user documentation handy for future reference.

NOTICE

■ Handling the Calculator

- Never try to take the calculator apart.
- When using paper, be sure you install it correctly.
- Paper jams are indicated by "P". Correct the problem as soon as possible.

■ Battery Operation

Any of the following indicates low battery power. Switch power off and replace batteries for normal operation.

- Dim display
- Printing problems

Important!

Note the following to avoid battery leakage and damage to the unit.



Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!