

PHILIPS

HD5120



EN	User manual	2
BG	Ръководство за потребителя	14
CS	Uživatelská příručka	26
DA	Brugervejledning	38
DE	Bedienungsanleitung	50
EL	Εγχειρίδιο χρήσης	62
ES	Manual de usuario	75
ET	Kasutusjuhend	87
FI	Käyttöopas	99
FR	Mode d'emploi	111
HR	Korisnički priručnik	123
HU	Használati útmutató	135
IT	Manuale dell'utente	147
KK	Пайдаланушы нұсқаулығы	159
LT	Naudotojo vadovas	171

LV	Lietošanas instrukcija	183
MK	Корисничко упатство	195
NL	Gebruiksaanwijzing	207
NO	Brakerhåndbok	219
PL	Instrukcja obsługi	231
PT	Manual do utilizador	243
RO	Manual de utilizare	255
RU	Руководство пользователя	267
SK	Příručka uživateľa	279
SL	Uporabniški priročnik	291
SQ	Manuali i përdorimit	303
SR	Korisnički priručnik	315
SV	Användarhandbok	327
UK	Посібник користувача	339
HE	המדריך למשתמש	351

Table of Contents

Introduction	3
Important safety information	3
Electromagnetic fields (EMF)	3
Device overview	4
Before first use	5
Brewing coffee	6
Drip stop function	9
Cleaning	9
Descaling	9
Ordering accessories	11
Warranty and support	11
Recycling	11
Troubleshooting	12

Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Important safety information

Read this important information carefully before you use the appliance and save it for future reference.

Danger

- Never immerse the appliance in water or any other liquid.

Warning

- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Connect the appliance to an earthed wall socket.
- Do not use the appliance if the plug, the mains cord or the appliance itself is damaged.
- If the mains cord is damaged, you must have it replaced by Philips, a service center authorized by Philips or similarly qualified persons in order to avoid a hazard.
- This appliance can be used by children aged from 8 years and above and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of reach of children aged less than 8 years.
- Children shall not play with the appliance.
- Do not let the mains cord hang over the edge of the table or worktop on which the appliance stands.
- Only use this appliance for its intended purpose to avoid potential hazard or injury.

Caution

- Always flush the appliance with fresh water before first use.
- Do not place the appliance on a hot surface and do not let the mains cord come into contact with hot surfaces.
- Do not place the appliance in a cabinet when in use.
- Unplug the appliance before you clean it and if problems occur during brewing.
- During brewing and until you switch off the appliance, the filter holder, the lower part of the appliance, the hotplate, and the jug filled with coffee are hot.
- Do not put the jug on a stove or in a microwave to reheat coffee.
- This appliance is intended to be used in household and similar applications such as farm houses, bed and breakfast type environments, staff kitchen areas in shops, offices and other working environments, and by clients in hotels, motels and other residential type environments.
- Always return the appliance to a service centre authorised by Philips for examination or repair. Do not open the appliance or attempt to repair the appliance yourself.

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Obsah je uzamčen

**Dokončete, prosím, proces objednávky.
Následně budete mít přístup k celému dokumentu.**



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!