

PHILCO®

Famous for Quality the World Over

**CONTACT GRILL
KONTAKTNÍ GRIL
KONTAKTNÝ GRIL
GRILL KONTAKTOWY
KONTAKTGRILL**



PHGR 9000

User's Manual
Návod k obsluze
Návod na obsluhu
Instrukcja obsługi
Használati utasítás

CONTENTS

1. IMPORTANT SAFEGUARDS	3
2. PRODUCT DISPLAY	4
3. CONTROL PANEL	4
4. TECHNICAL SPECIFICATION	4
5. BEFORE USE	4
CLOSED POSITION	4
OPEN POSITION	5
HORIZONTAL PLACEMENT	5
REMOVE THE BAKING TRAY	5
REMOVE OIL-RECEIVING BOX.....	5
SPECIFIC OPERATION STEPS	6
6. AUTOMATIC GEAR RECIPE	6
7. CARE AND CLEANING	7
8. FAULT EXPLANATION	7

Dear customer,

Thank you for buying a PHILCO brand product. So that your appliance serves you well, please read all the instructions in this user's manual.

1. IMPORTANT SAFEGUARDS

IMPORTANT NOTE: Please read the manual carefully before operating your product. Retain it for future reference.

Please refer to different parts of this manual or corresponding icons before operation, maintenance, and installation of products.

When using electrical appliances, basic safety precautions should always be followed:

1. Read all instructions before using the machine.
2. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
3. Children shall not play with the appliance. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
4. This appliance is intended to be used in household and similar applications such as:
 - Staff kitchen areas in shops, office and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments;
5. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
6. Please turn off and unplug the appliance before cleaning, maintenance or relocation and whenever it is not in use.
7. This appliance as well as the cooking utensils used and the surface of the appliance can become very hot, do not touch the hot surface of the hob.
8. That appliances are not intended to be operated by means of an external timer or separate remotecontrol system.
9. In order to prevent electric shock, please do not immerse the power cord and plug or part of them in water or other liquids.
10. Power supply should be cut off when it is not in use or before cleaning. Please clean the baking tray after it cools down.
11. Please do not put it on hot coal gas or electric stoves, or in a heated oven.
12. Care should be taken when moving appliances containing hot oil or other hot liquid.
13. Do not heat or preheat without two cooking trays in the grill.
14. To disconnect, turn any control to „off,“ then remove plug from wall outlet.
 - a) A short power-supply cord is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
 - b) Longer extension cords are available and may be used if care is exercised in their use.
 - c) If a long extension cord is used:
 - 1) The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance;
 - 2) The longer cord should be arranged so that it does not drape over the countertop or table top where it can be pulled on by children or tripped over unintentionally.

HOUSEHOLD USE ONLY SAVE THESE INSTRUCTIONS

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!