

For FAQs and more information, please visit:

anker.com/support



@anker_official
@anker_jp



@Anker Deutschland
@Anker Japan
@Anker



@AnkerOfficial
@Anker_JP



Product Number: A2568 51005002978 V01

English	01
Čeština	06
Dansk	09
Deutsch	11
ελληνικά	14
Español	17
Suomi	20
Français	23
Magyar	26
Italiano	28
Nederlands	31
Norsk	34
Język polski	37

Português	40
Русский	43
Slovenský Jazyk	46
Slovenski Jezik	49
Svenska	52
Türk	55
日本語	58
한국어	60
简体中文	62
繁体中文	65
العربية	67
עברית	70

LED Indicators	Status
Solid white for 3 seconds, then turn off	Connected to power
Light up one by one, then turn off	Charging your phone
/	Charging your earbuds
Flash white	Metal objects detected
Only LED lights on the two sides flash white	- Overvoltage or undervoltage protection - Incompatible AC adapter connected, indicating that you need to switch to a Quick Charge 2.0/3.0 or Power Delivery adapter



- This wireless charger is not compatible with non-Magsafe phone cases, such as Otterbox Defender cases.
- It is not advised to charge a phone on the earbuds charging area.
- When the angle between the phone charging part and the base is less than 40°, the wireless earbuds charging function will turn off automatically for safety.
- Connect the wireless charger to a Quick Charge 2.0/3.0 or Power Delivery wall adapter. Do not connect to a 5V/1A wall charger or a USB port on a computer as it may affect the wireless charging function.
- Do not place any foreign objects between your device and the wireless charger's surface, including metal pads on a car mount, magnetic cards, door keys, coins, NFC cards, or other metal objects, as they could potentially demagnetize the wireless charger, affect the charging speed, or cause overheating.

- Wireless chargers make charging more convenient than wired chargers, but confined by current wireless technology, their charging speed is slower than that of wired chargers.
- High temperatures will reduce charging speed and restrict power. It is recommended that you charge your device in environments with temperatures below 40°C / 104°F.

Important Safety Instructions



Please refer to the electrical and safety information on the bottom before installing or operating the product.

- Avoid dropping.
- Do not disassemble.
- Do not expose to liquids.
- This product is suitable for moderate climates only.
- The maximum ambient temperature during use of this product must not exceed 40°C.
- Open flame sources, such as candles, must not be placed on this product.
- Only use a dry cloth or brush to clean this product.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!