




Mechanical Gaming RGB keyboard



**EN****Mechanical Gaming RGB keyboard****CZ****Herní mechanická RGB klávesnice****SK****Herná mechanická RGB klávesnica****PL****Mechaniczna klawiatura do gier RGB****HU****Mechanikus RGB játék billentyűzetk****RS****Mehanička RGB tastatura za igranje****HR****Mehanička RGB tipkovnica za igre****EL****Mηχανικό πληκτρολόγιο RGB Gaming****USER'S MANUAL****NÁVOD K OBSLUZE****NÁVOD NA OBSLUHU****INSTRUKCJA OBSŁUGI****HASZNÁLATI ÚTMUTATÓ****UPUTSTVO ZA UPOTREBU****KORISNIČKI PRIRUČNIK****ΕΓΧΕΙΡΙΔΙΟ ΧΡΗΣΤΗ**



<b>Fn</b> +	Opens the "My Computer" window.	<b>Fn</b> +	Starts/pauses the currently playing audio/video track.
<b>Fn</b> +	Opens your default web browser. If it is already running or if you are already working in it, a new tab will open when you press this shortcut.	<b>Fn</b> +	Switches to the next audio/video track.
<b>Fn</b> +	Runs your default e-mail client in the computer.	<b>Fn</b> +	Stops the currently playing audio/video track.
<b>Fn</b> +	Runs the default music player in your operating system.	<b>Fn</b> +	Opens the search window in the operating system.
<b>Fn</b> +	Switches to the previous audio/video track.	<b>Fn</b> +	Displays the favorites in the web browser.
<b>Fn</b> +	Slows down the animation of the current effect (3 levels).	<b>Fn</b> +	Decreases the keyboard backlight (5 levels).
<b>Fn</b> +	Speeds up the animation of the current effect (3 levels).	<b>Fn</b> +	Increases the keyboard backlight (5 levels).
<b>Fn</b> +	Slows down the animation of the effect of the circumferential RGB bar (5 levels).	<b>Fn</b> +	Changes the colour of the current effect to one of eight solid colours.
<b>Fn</b> +	Decreases the brightness of the circumferential RGB bar (5 levels + off).	<b>Fn</b> +	Changes the current effect to one of 11 rainbowlike and colour animations.
<b>Fn</b> +	Speeds up the animation of the effect of the circumferential RGB bar (5 levels).	<b>Fn</b> +	Starts browsing through five profiles for individual setting of the layout of the button backlight. The currently selected profile is indicated by backlighting the button within the range of 1 to 5 above the letter area.
<b>Fn</b> +	Increases the brightness of the circumferential RGB bar (5 levels + off).	<b>Fn</b> +	Changes the backlight effect of the circumferential RGB bar (6 effects).
<b>Fn</b> +	Changes the colour/direction of the backlight of the circumferential RGB bar.	<b>Fn</b> +	Starts recording a custom user backlight.
<b>Fn</b> +	Reactive effects of the keyboard backlight. The backlight reacts to and changes according to the presses of the button (5 effects).	<b>Fn</b> +	Factory reset of the whole keyboard. Hold the shortcut for three seconds. A successful restart is indicated by three flashes of the keyboard.
<b>Fn</b> +	Breathing effects of the backlight. Effects that light up and down slowly and change colour.	<b>Fn</b> +	

# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.**

**Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přizívají na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!