

"PD10-HD"

10000 mAh

Power Pack



GB Operating instruction

Thank you for choosing a Hama product.

Take your time and read the following instructions and information completely. Please keep these instructions in a safe place for future reference. If you sell the device, please pass these operating instructions on to the new owner.

1. Explanation of Warning Symbols and Notes





This symbol is used to indicate safety instructions or to draw your attention to specific hazards and risks.

Note



This symbol is used to indicate additional information or important notes.

High-density lithium-polymer cells

This product contains high-density lithium-polymer cells. High-density cells were developed mainly for smartphone production in order to meet the high capacity and performance demands using a minimum amount of space. This new generation of lithium-polymer cells enables a lightweight and compact design along with a comparatively high capacity.

2. Package Contents

- Power Pack "PD10-HD", 10000 mAh
- · USB-C to USB-C cable
- · These operating instructions

3. Safety Notes

- The product is intended for private, non-commercial use only.
- Use the product for its intended purpose only.
- Protect the product from dirt, moisture and overheating, and only use it in a dry environment.
- Do not use the product in the immediate vicinity of heaters or other heat sources or in direct sunlight.
- Keep this product, as all electrical products, out of the reach of children!
- Do not drop the product and do not expose it to any major shocks.
- Do not operate the product outside the power limits given in the specifications.
- Do not open the device or continue to operate it if it becomes damaged.
- Dispose of packaging material immediately according to locally applicable regulations.
- Since the battery is integrated and cannot be removed, you will need to dispose of the product as
 a whole. Do this in compliance with the legal requirements.
- Do not modify the product in any way. Doing so voids the warranty.
- Do not use the product in areas where the use of electronic devices is not permitted.
- Do not attempt to service or repair the product yourself. Leave any and all service work to qualified
 experts.
- Do not throw the battery or the product into fire.
- Do not tamper with or damage/heat/disassemble the batteries/rechargeable batteries.

4. Operation

4.1 Charging the Power Pack

Warning - Battery



- Do not charge the power pack using your PC or the notebook. The charging currents can damage the USB port of the PC/notebook.
- · Only use suitable charging devices or USB connections for charging.
- As a rule, do not charge devices or USB connections that are defective and do not try to repair them yourself.
- · Do not overcharge the product or allow the battery to completely discharge.
- Avoid storing, charging or using the device in extreme temperatures and extremely low atmospheric pressure (for example, at high altitudes).
- When stored over a long period of time, batteries should be charged regularly (at least every three months).
- Begin charging the power pack by connecting the included USB-C to USB-C cable to the power
 pack's USB-C (IN 5V/3A; 9V/2A) port and to a suitable USB-C charger. Alternatively, the power
 pack can also be charged via the Micro-USB port. For this purpose, connect a Micro-USB cable to
 the Micro-USB input (IN 5V/3A; 9V/2A) on the power pack and to a suitable USB charger. Please
 refer to the operating instructions for the USB charger used.
- · Charging begins and ends automatically.
- Charge the Power Pack fully before using it for the first time.

Note - Capacity



- The capacity is always shown when the Power Pack is charging.
 Each status LED corresponds to 25% of the capacity. When an LED is permanently illuminated, this indicates that this capacity level has already been reached. The Power Pack is charged to at least 75% if three LEDs are illuminated, and the fourth is flashing.
- · If all four status LEDs light up, the full capacity is available.
- · Press the button of the Power Pack to switch it on and to check its current capacity.
- · To switch the power pack off, press the button twice until the status LEDs go out.

4.2 Charging terminal devices

Warning – Connecting terminal devices



- Before connecting a terminal device, check whether the power output of the charger can supply sufficient power for the device.
- Ensure that the total power consumption of the connected terminal device does not exceed 3000 mA.
- Please refer to the instructions in the operating manual of your terminal device.
- It is essential that you observe these specifications and the safety instructions regarding the power supply of your devices.
- · The power pack must not be charged and discharged at the same time!
- Please do not use the USB and USB-C outputs simultaneously for charging, as this reduces the charging current considerably. As a result, the charging time is greatly increased and the power pack may be overloaded.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.
 - *) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.
- 2) Pak jsou tady "roboti", kteří se přiživují na naší práci a "vysávají" výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!